

PARTS INCLUDED WITH EQUIPMENT

INSTRUCTIONS

barbecue – 4 section

1. Ensure all burners are in the “OFF” position (parallel to the front of the barbecue)
2. Turn propane on at the source and wait 5 minutes before ignition.
3. Make sure that you have an ignition source ready to go.
4. Turn one burner only to “ON” position (valve handle pointing out from barbecue). Ignite from the top of the unit. By holding flame on the lava rock in front of where the gas valve is situated (the burner is a long straight tube that comes directly from the burner valve).
5. When burner is fully lit, turn other burner to “ON”. It will ignite on from the first burner.
6. Proceed to light the other sections in the same manner.
7. When finished, turn propane off at the tank and allow the barbecue flames to extinguish.

PROPANE REQUIREMENTS?

VANCOUVER SHOWROOM INFO

#50 - 3711 North Fraser Way
Burnaby, B.C. V5J5J2
(P) 604-324-7368
(F) 604-324-6667
Toll Free: 1-877-379-7368

SEATTLE SHOWROOM INFO

4604 – 4th Avenue South
Seattle, WA 98134
(P) 206-749-5400
(F) 206-749-5432
Toll Free: 1-866-885-7368

The logo for Pedersen's, featuring the brand name in a stylized, cursive script font with a horizontal line underneath.

THE CELEBRATION EXPERTS

VANCOUVER, B.C. - SEATTLE, WA
www.pedersens.com

AFTER HOURS EMERGENCY INFO

Should an emergency arise after hours, please call your local Pedersen's office and your call will be directed to a staff member who can assist you.