

PARTS INCLUDED WITH EQUIPMENT

INSTRUCTIONS

griddle

1. Ensure that the propane is hooked up properly.
2. Check that all burner valves are in the horizontal position (“OFF”).
3. Turn the propane tank on 5 minutes before ignition.
4. Have ignition device ready to go.
5. Turn the front burner “ON” only AND ignite it immediately.
6. When the front burner is fully lit, turn on the second burner and finally the third burner.
7. Turn off the griddle by turning off the propane tank first.

PROPANE REQUIREMENTS?

VANCOUVER SHOWROOM INFO

#50 - 3711 North Fraser Way
Burnaby, B.C. V5J5J2
(P) 604-324-7368
(F) 604-324-6667
Toll Free: 1-877-379-7368

SEATTLE SHOWROOM INFO

4604 – 4th Avenue South
Seattle, WA 98134
(P) 206-749-5400
(F) 206-749-5432
Toll Free: 1-866-885-7368

The logo for Pedersen's, featuring the brand name in a stylized, cursive script font with a horizontal line underneath.

THE CELEBRATION EXPERTS

VANCOUVER, B.C. - SEATTLE, WA
www.pedersens.com

AFTER HOURS EMERGENCY INFO

Should an emergency arise after hours, please call your local Pedersen's office and your call will be directed to a staff member who can assist you.