



Table Top Convection Oven (Large) Operating Instructions

1. Position the oven on the counter/table with at least 2" of air space on all sides of the oven
2. Plug convection oven directly into a wall outlet
3. Position the three shelves with as much space between them as possible for good air flow to allow for even cooking
4. Set the temperature dial to the desired temperature. The light beside the temperature knob will go on. When the oven reaches the desired temperature the light will shut off and the oven is ready for use
5. Set the timer dial. This can be set to "Continuous On" or to a desired cooking time
 - a. Continuous On: Turn the timer knob counter clockwise to the "ON" position and the oven will remain on until it is turned to "OFF"
 - b. Desired Cooking Time: Turn the timer knob to the desired cooking time (up to 120 minutes). The oven will automatically turn off when the time expires.
6. When finished use, turn temperature dial to "0" and turn the timer to "OFF"
7. Unplug the oven from the wall and allow to cool before returning it to the box